

TYA3ECRC SERIES MERCHANDISER with R-454C Refrigerant

WARNINGS:

If the information in these instructions are not followed exactly, a fire or explosion may result, causing property damage or personal injury.

Installation and service must be performed by a qualified installer or service agency.

**READ THE ENTIRE MANUAL BEFORE
INSTALLING OR USING THIS EQUIPMENT.**

The unit uses R-454C gas as the refrigerant. R-454C is flammable and heavier than air. It collects first in low areas but can be circulated by the fans. If R-454C gas is present or even suspected, do not allow untrained personnel to attempt to find the cause. The R-454C gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas. If a leak is detected, immediately evacuate all persons from the store, and contact the local fire department to advise them that an R-454C leak has occurred. Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store. No open flames, cigarettes or other possible sources of ignition should be used inside or in the vicinity of the units.

**FAILURE TO ABIDE BY THIS WARNING COULD
RESULT IN AN EXPLOSION, INJURY AND
PROPERTY DAMAGE.**

IMPORTANT
Keep in store for future reference!



Installation, Operation and Service Manual

P/N 3211995

June 2025

Rev. C




BEFORE YOU BEGIN

Read these instructions completely and carefully.



PERSONAL PROTECTION EQUIPMENT (PPE)

Personal Protection Equipment (PPE) is required whenever installing or servicing this equipment. Always wear safety glasses, gloves, protective boots or shoes, long pants, and a long-sleeve shirt as required when installing or servicing this equipment.



1. If the information in these instructions are not followed exactly, a fire or explosion may result, causing property damage or personal injury.
2. Installation and service must be performed by a qualified installer or service agency.
3. This unit is designed only for use with R-454C gas as the designated refrigerant.

THE REFRIGERANT LOOP IS SEALED. ONLY A QUALIFIED TECHNICIAN SHOULD ATTEMPT TO SERVICE!

- R-454C is flammable and heavier than air.
- It collects first in the low areas but can be circulated by the fans.
- If R-454C is present or even suspected, do not allow untrained personnel to attempt to find the cause.
- The R-454C gas used in the unit has no odor.
- The lack of smell does not indicate a lack of escaped gas.
- If a leak is detected, immediately evacuate all persons from the store, and contact the local fire department to advise them that a propane leak has occurred.
- Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store.
- A hand-held R-454C leak detector ("sniffer") shall be used before any repair and/or maintenance.
- No open flames, cigarettes or other possible sources of ignition should be used inside the building where the units are located until the qualified service technician and/or local fire department determines that all R-454C has been cleared from the area and from the refrigeration systems.
- Component parts are designed for R-454C and non-incendive and non-sparking. Component parts shall only be replaced with identical repair parts.

FAILURE TO ABIDE BY THIS WARNING COULD RESULT IN INJURY AND PROPERTY DAMAGE.



This warning does not mean that Hussmann products will cause cancer or reproductive harm, or is in violation of any product-safety standards or requirements. As clarified by the California State government, Proposition 65 can be considered more of a 'right to know' law than a pure product safety law. When used as designed, Hussmann believes that our products are not harmful. We provide the Proposition 65 warning to stay in compliance with California State law. It is your responsibility to provide accurate Proposition 65 warning labels to your customers when necessary. For more information on Proposition 65, please visit the California State government website.



ANSI Z535.5 DEFINITIONS



• **DANGER** – Indicate[s] a hazardous situation which, if not avoided, will result in serious injury.




• **WARNING** – Indicate[s] a hazardous situation which, if not avoided, could result in serious injury.



• **CAUTION** – Indicate[s] a hazardous situation which, if not avoided, could result in minor or moderate injury.



• **GROUNDING CONNECTION** – Indicate[s] a grounding connection on the appliance.



• **MINIMUM ROOM FLOOR AREA** – Indicate[s] the minimum floor area required for installation of the appliance.



• **DANGER** – Indicate[s] a risk of fire or explosion. Flammable refrigerant used. To be repaired only by trained service personnel. Do not puncture refrigerant tubing.

• **NOTICE** – *Not related to personal injury* – Indicate[s] situations, which if not avoided, could result in damage to equipment.

⚠ WARNING

Keep all ventilation openings clear of obstruction.

All installation and operating instructions concerning the handling, moving, and use of these merchandisers must be carefully followed to avoid either damaging the refrigerant tubing, or increasing the risk of a leak.

Do not damage the refrigerant circuit.

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).

Do not pierce or burn.

Be aware that refrigerants may not contain an odour.

⚠ WARNING

Do not use electrical appliances inside the food/storage compartments unless they are of the type recommended by the manufacturer.

In order to reduce flammability hazards, the installation of this appliance must only be carried out by a suitably qualified person.

Component parts shall be replaced with like components, and servicing shall be done by factory authorized service personnel only, so as to minimize the risk of possible ignition due to incorrect parts or improper service.

Product will degrade and may spoil if allowed to sit in non-refrigerated area.

Table of Contents

CONTENT	SUB CONTENT	PAGE
Notice on Loading and Handling		6
General Information		7-8
Section and Plan Views		9-10
Installation	Preparation	11-12
	Lifting & Transportation - Using J-Bars & Dollies	13
	ForkLift Guidance	14
	Method for Leveling	15
	Body Panels	16
User Information	Startup and Setup	17
	Checklist	18
Maintenance	Cleaning Exterior and Interior	20-21
	Maintenance Tips	22
Electrical	General Information	23-24
	Component Locations	25
	Self-Contained Component Locations	26
	Controller Information	27-30
Refrigeration	Leak Detection	31
	Serial Plate Location /Piping	32
	Service and/or Repair	33-35
	Water Outlet	36
Trouble Shooting		37-38
Service	Remove Scratches from Perimeter Plex	39
	Evaporator Fan Replacement	40-41
	LED Driver Replacement	42-43

IMPORTANT
KEEP IN STORE FOR FUTURE REFERENCE
Quality that sets industry standards!

1299 St. Charles Rock Road Bridgeton, MO 63044-2483
U.S. & Canada 1-800-922-1949 Mexico 800-890-2900

www.hussmann.com



© 2024 Hussman Coporation

Notice



WARNING

- DO NOT Load or stand over the top of the case.
Glass breakage may occur if precautions are disregarded.
- Broken glass can cause lacerations, cuts, and puncture wounds which may result in severed arteries or tendons, amputations, eye injuries, or exposure to disease.



IMPORTANT

- DO NOT ATTEMPT TO MOVE THE MERCHANDISER BY APPLYING FORCE TO THE GLASS/PLEX AREA (EVEN IF WOODEN BRACES ARE PRESENT)
- APPLY PUSHING FORCES NEAR THE LINER / TUB AREA IN ORDER TO BRING MERCHANDISERS TO THE FINAL POSITION

General Information

Case Description:

Description: Merchandiser

Shipping Damage: All equipment should be thoroughly examined for shipping damage before and during unloading. This equipment has been carefully inspected at our factory and the carrier has assumed responsibility for safe arrival. If damaged, either apparent or concealed, claim must be made to the carrier Immediately.

Apparent Loss or Damage: If there is an obvious loss or damage, it must be noted on the freight bill or express receipt and signed by the carrier's agent; otherwise, carrier may refuse claim. The carrier will supply necessary claim forms.

Concealed Loss or Damage: When loss or damage is not apparent until after all equipment is uncrated, a claim for concealed damage is made. Make request in writing to carrier for inspection within 15 days and retain all packaging. The carrier will supply inspection report and required claim forms.

Shortages: Check your shipment for any possible shortages of material. If a shortage should exist and is found to be the responsibility of Hussmann, notify Hussmann. If such a shortage involves the carrier, notify the carrier immediately, and request an inspection. Hussmann will acknowledge shortages within ten days from receipt of equipment.

Hussmann Product Control: The serial number and shipping date of all equipment have been recorded in Hussmann's files for warranty and replacement part purposes. All correspondence pertaining to warranty or parts ordering must include the serial number of each piece of equipment involved, in order to provide the customer with the correct parts.

Location/Store Conditions: The TYA3ECRC merchandiser has been designed for use only in air-conditioned stores where temperature and humidity are maintained at or below 75°F Dry bulb and 55% relative humidity. The case is also rated to operate in Type 2 conditions (80F / 55%RH). See specification sheets for setting changes. DO NOT allow air conditioning, electric fans, ovens, open doors or windows (etc.) to create air currents around the merchandiser, as this will impair its correct operation.

Keep this booklet with the case at all times for future reference.

HUSSMANN®



This equipment is to be installed to comply with the applicable NEC, Federal, State, and Local Plumbing and Construction Code having jurisdiction.

General Information

This appliance is accessible to the General Public.

This appliance has not been evaluated for use at elevations above 2,000 meters (6,562 Ft.).

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

This appliance and interconnecting refrigerant piping is to be installed in accordance with the Safety Standard for Refrigeration Systems, ANSI/ASHRAE 15.

This appliance shall not be installed in public corridors or lobbies.

A means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.

If the SUPPLY CORD is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.

This equipment is intended for installation within a motor fuel dispensing facility. This equipment is to be installed and used in accordance with the National Electrical Code, NFPA 70, and the Code for Motor Fuel Dispensing Facilities and Repair Garages, NFPA 30.

The refrigerator or freezer is to be mounted at least 450 mm (18 in) above grade level.

The test room climate class for this appliance is Climate Class 8. Climate Class 8 means the unit has been tested for maximum ambient of 75°F dry bulb and 55% relative humidity.

All piping material, pipe routing, and installation shall include protection from physical damage in operation and service and be in compliance with national and local codes and standards, such as ANSI/ASHRAE 15, IAPMO Uniform Mechanical Code, ICC International Mechanical Code, or CSA B52. All field joints shall be accessible for inspection prior to being covered or enclosed.

Precautions shall be taken to avoid excessive vibration or pulsation.


If this appliance is installed in an unventilated area, provisions must be made so that in the event of a refrigerant leak, the refrigerant will not stagnate so as to create a fire or explosion hazard. If the appliance is non-fixed, it shall be stored in an area where the room size corresponds to the room area as specified for operation and it shall be stored in a room without continuously operating open flames or other potential ignition sources.

For appliances using A2L REFRIGERANTS, connected via an air duct system to one or more rooms, the supply and return air shall be directly ducted to the space. Open areas such as false ceilings shall not be used as a return air duct.

Case Sections

3X4.5


3X5.5




Case Plan Views

3X4.5

3X5.5






Installation – Preparation

Receiving Case and Preparing for Installation

IMPORTANT

-PLASTIC WRAP MAY BE REMOVED TO ACCESS PARTS, WARNINGS, AND INSTRUCTIONS




Prepare By:

1. Inspect equipment for damage. Any claim for loss or damage must be made to the carrier. The carrier will provide any necessary inspection/claim form. If there is obvious loss or damage, it must be noted on the freight bill or express receipt and signed by the carrier's agent; otherwise carrier may refuse claim.
2. Read instructions and warnings on handling and transportation. Ensure the proper transportation equipment is being used.
3. Survey and mark out the installation area and plan footprint. Snapping chalk lines is recommended.


Snapping Chalk Lines

Mark floors with Chalk snap lines where cases are to be located. Chalk lines are to run along the base or legs of cases.



Installation – Preparation

Receiving Case and Preparing for Installation



MERCHANDISER WILL
BE ON A PALLET

1. Remove all 4 shipping brackets from case & pallet
2. Lift & slide case off pallet and place on floor or dollies. J-bar may be used to lift case (see next page for placement).


Installation – Lifting and Transportation – Using J-Bars and Dollies

TYA3ECRC Transportation Using Dollies


Using J-Bars to get the merchandizer onto Dollies for transportation is the preferred and recommended technique for getting the case to its final location.

1. Remove lower body panels before lifting with a J-Bar to prevent damage.
2. The TYA3ECRC can be lifted with a J-Bar high enough to place furniture dollies under each base leg.
3. Engage the TYA3ECRC from the points illustrated in the Image Below.
4. Ensure the case is balanced before attempting to place on dollies. Reposition J-Bar if necessary.
5. Lift the case only as high as necessary to place a dolly.
6. Repeat the procedure at the other end and in the center as necessary.
7. TYA3ECRC (base legs) cases require 2 dollies.
8. Evenly support the entire base structure on rollers or dollies before attempting to move.

Each Base Leg must have its own dolly to properly support the case.



- A. Safe J-Bar Lift Point centered on the left/right side of case
- B. Lift one side at a time with J-Bar
- C. Insert Dollies here one at a time





Installation – Lifting and Transportation – Fork-Lift Guidance

TYA3ECRC Transportation using Fork-Lifts

Using J-Bars and Dollies are the preferred technique, but a Fork-Lift can be used if the special requirements stated below are met

1. Remove lower body panels before lifting with a forklift to prevent damage
2. Before lifting the case, be sure forklift blades clear all base legs. See Image Below.
3. The case can be raised at one end under the base leg to allow for placement of dollies.



Installation – Method for Leveling TYA3ECRC Merchandisers

Important: See the suggestions for setting cases on uneven floors before setting lineups and leveling cases. Using this suggestion will result in the fewest required adjustments to case levels.

NOTICE

Longer length cases may require shims along the center portion of the case to maintain proper case alignment, performance, and drainage.

Place bubble level on front ledge to check side-to-side levelness


IMPORTANT!

Measure levelness on both ends if level tool is not long enough to cover the entire span

Place bubble level on top panel to check for front-to-back levelness

IMPORTANT!

Both panels should have even levels in order to prevent twisting



1

2

Use Metal Shims

Level the Case sequentially, Using Metal Shims

1. Check levelness left-to-right first (This usually requires the most correction on a single side)
2. Adjust front-to-back levelness after ensuring left-to-right levelness (Shims normally inserted in pairs during this check).


Important: Always level the first case in the lineup. All other cases should be driven from its levels. See “Uneven Floor Guidance” for details.

Note: The use of metal shims is recommended in order to prevent shim deterioration over time

Installation – Installing Access Panel

Installing Removable Access Panel

Lift panel up and pull panel out of bridge lance. See Image Below..



1. Removable Access Panel.

User Information

Start Up

See the merchandisers Data Sheet Set for refrigerant settings and defrost requirements. Bring merchandisers down to the operating temperatures listed on the Data Sheet.

See page 25 for electrical component locations

Condensate Evaporator Pan Setup


Setup:

The merchandiser comes factory equipped with an Evaporator Pan, to which the drain pipes from the case feed condensate water into. There are multiple levels to collect excess water that may overspill in case of store conditions being above design specification causing more condensate water to be formed than expected.

Clearances

-Minimum Clearances for Self-Contained case are to be followed as instructed for proper placement inside store locations.

- Intake and exhaust clearances are to be a minimum of 8 ft when placed next to a solid wall.
- Height clearance measured from floor is a minimum of 10 ft vertically.
- Minimum of 36 in. clearance if near an open aisle is required for proper cycle ventilation.
- Case set location to be at least 15 ft away from any entrance/exit door.
- The minimum floor area of the room shall be 260 Ft.² with ventilation.



Case	Do not exceed Max Load (evenly distributed) per pan.
TYA3ECRC3X45ESPA	100 lbs. (45.4 kg)
TYA3ECRC3X55ESPA	75 lbs. (34.0 kg)
TYA3ECRC5X7ISPA	125 lbs. (56.7 kg)

Case	Do not exceed Max Load (evenly distributed) per shelf.
TYA3ECRC3X45ESPA	90 lbs. (40.8 kg)
TYA3ECRC3X55ESPA	120 lbs. (54.4 kg)
TYA3ECRC5X7ISPA (10")	60 lbs. (27.2 kg)
TYA3ECRC5X7ISPA (12")	70 lbs. (31.7 kg)

Product Loading


Please keep product within the appropriate load limit.

The load limit is indicated with a line on the case as shown on the right.

It is important that the case is not overloaded with product, this would block the airflow pattern.

Proper loading of product ensures the case refrigerates as specified.

CAUTION: Obstructing air vents will affect case performance which could potentially lead to case failure.



User Information

Pre-Power Checklist

- ☐ Review all safety warnings on the case and in this manual (pg. 1-4).
- ☐ Examine the entire case for any shipping damage (pg 11-12).
- ☐ The case should be level and all casters (if applicable) are in locked position (pg 15).
- ☐ Verify that the fan plenums are in place.
- ☐ Inspect all refrigeration lines for holes, dents or kinks.
- ☐ Verify that the power receptacle has matching voltage and amp ratings.
- ☐ Ensure that the case switch is in the OFF position prior to plugging the cord into the receptacle (pg 26).

Powered Up Checklist

- ☐ Verify the case temperatures and adjust the controller as needed, consult data sheet.
- ☐ Install all the exterior lower panels (pg 16).
- ☐ Allow the case to operate at least two (2) hours before placing product inside to ensure the case is at proper operating temperature.
- ☐ Load the case per loading requirements (pg 17).

User Information

Review all safety warnings on the case and in this manual (pg. 2-4) before providing any service or Maintenance

WARNINGS:

If the information in these instructions are not followed exactly, a fire or explosion may result, causing property damage or personal injury.

Installation and service must be performed by a qualified installer or service agency.

READ THE ENTIRE MANUAL BEFORE INSTALLING OR USING THIS EQUIPMENT.

The unit uses R-454C gas as the refrigerant. R-454C is flammable and heavier than air. It collects first in low areas but can be circulated by the fans. If R-454C gas is present or even suspected, do not allow untrained personnel to attempt to find the cause. The R-454C gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas. If a leak is detected, immediately evacuate all persons from the store, and contact the local fire department to advise them that an R-454C leak has occurred. Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store. No open flames, cigarettes or other possible sources of ignition should be used inside or in the vicinity of the units.

**FAILURE TO ABIDE BY THIS WARNING COULD
RESULT IN AN EXPLOSION, INJURY AND
PROPERTY DAMAGE.**

IMPORTANT

Keep in store for future reference!

Maintenance

Case Cleaning

Long life and satisfactory performance of any equipment are dependent upon the care it receives. To ensure long life, proper sanitation and minimum maintenance costs, the merchandiser should be thoroughly cleaned, all debris removed, and interiors washed down weekly.

Exterior Surfaces

The exterior surfaces must be cleaned with a mild detergent without chloride and warm water to protect and maintain their attractive finish. **NEVER USE ABRASIVE CLEANSERS OR SCOURING PADS.**

Cleaning Bumpers

Clean bumpers with household spray cleaners.

Cleaning Under Merchandiser

Remove lower body panels. Use a vacuum with a long wand attachment to remove accumulated dust and debris from under the merchandiser. Use a vacuum only if it has been certified for use around flammable refrigerants.

Cleaning Stainless Steel Surfaces

Use non-abrasive cleaning materials, and always polish with the grain of the steel. Use warm water or add a mild detergent to the water and apply with a cloth. Always wipe dry after wetting.

Use non-chlorine containing cleaners such as window cleaners and mild detergents. Do not use cleaners containing salts as this may cause pitting and rusting of the stainless-steel finish. Do not use bleach.

Clean frequently to avoid build-up of hard, stubborn stains. A stainless-steel cleaning solution may be used periodically to minimize scratching and remove stains.

Rinse and wipe dry immediately after cleaning. Never use hydrochloric acid (muriatic acid) on stainless steel.

Interior Surfaces

The interior surfaces may be cleaned with most domestic detergents, ammonia-based cleaners and sanitizing solutions that do not contain chloride with no harm to the surface.

Cleaning Coils

NEVER USE SHARP OBJECTS AROUND COILS.

Use a soft brush or vacuum brush to clean debris from coils. Do not puncture Coils! Do not bend fins. Contact an authorized service technician if a coil is punctured, cracked, or otherwise damaged.

ICE in or on the coil indicates the refrigeration and defrost cycle is not operating properly. Contact an authorized Service Technician to determine the cause of icing and to make proper adjustments as necessary. To maintain product integrity, move all product to a cooler until the merchandiser has returned to normal operating temperatures.

Cleaning Honeycomb

NEVER USE SHARP OBJECTS AROUND HONEYCOMB.

The Honeycomb must be cleaned with a mild detergent without chloride and warm water to protect and maintain their attractive finish. **NEVER USE ABRASIVE CLEANSERS OR SCOURING PADS.**

Do Not Use:

- Abrasive cleaners and scouring pads, as these will damage the finish.
- Solvent, oil or acidic based cleaners on any interior surfaces.

Maintenance

Cleaning Condenser Coils

Coils should be cleaned at least once per month. Additional cleaning may be required depending on environment. A dirty condenser blocks normal airflow through the coils.

Airflow blockage increases energy consumption & reduces the merchandiser's ability to maintain operating temperatures.

To clean the coils, use a vacuum cleaner with a wand attachment & a soft (non-metallic) brush to remove dirt & debris. Do not bend fins. Always wear gloves & protective eye wear when cleaning near sharp coil fins & dust particles. Use a vacuum only if it has been certified for use around flammable refrigerants.

Cleaning Honeycomb

A dirty Honeycomb will block normal air flow. The Honeycomb should be inspected at least once per month. Clean as necessary after inspection. More frequent inspection/cleaning may be required depending on the environment.

NSF Compliant Sealing of The Case to The Floor

When the appliance is designed to be sealed to the floor or countertop the following procedure must be followed to establish proper sanitary operation. First, ensure the floor area is clean and free from debris. Begin by positioning the appliance in its designated installation spot, ensuring sufficient clearance on the back and sides according to the specified "Clearances" for proper ventilation. Next, level the appliance from front to back and side to side, as described in "Method for Leveling." Once level, outline the base of the appliance on the floor. Then, lift and support the front of the appliance. Apply a bead of NSF-approved sealant to the floor, positioned about 1/2 inch (13 mm) inside the front part of the outline. The bead should be substantial enough to cover the entire appliance surface when lowered onto it. Afterward, raise and support the rear of the appliance and apply the sealant to the floor along the remaining three sides. Finally, carefully lower the appliance and inspect it to ensure a complete seal around the entire perimeter and clean off any extra sealant as necessary. Once the appliance is sealed in accordance with these procedures, the result is intended to prevent liquid spillage on adjacent surfaces of the floor or countertop from passing under inaccessible portions of the equipment.

Maintenance

Condensate Evaporator Pan Maintenance

Maintenance:

Care must be taken to ensure that the condensate pans operate properly at the store. These units are designed to operate at either 75°F ambient and 55% relative humidity (RH) or 80°F ambient and 55% relative humidity (RH). If stores are operating above this condition, case performance will be severely affected. If such a condition is noted, Evaporator Pan must be checked periodically to see if excess water is being collected. If water has accumulated, water must be siphoned out of pan. Care must be taken while performing this setup. Unit power should be shut off for electrical safety. Once water has been removed and pan is dried out, unit power can be turned back on. Correct the store conditions and ensure temperature and relative humidity are within stated parameters. Call a HVAC technician if the A/C is not working properly.

See pg 26. Item 4

Cleaning Process Overview:

- Remove the product and all loose debris to avoid clogging the waste outlet.
- Store product in a refrigerated area such as a cooler during the cleaning process.
- Remove only as much product as can be taken to the cooler in a timely manner.
- **First, turn off refrigeration, then disconnect electrical power to merchandiser.**
- Thoroughly clean all surfaces with soap and hot water.
 - Do not use steam or high-pressure water hoses to wash the interior.
 - These techniques will damage sealing causing leaks and poor performance.
- Avoid direct contact between fan motors and cleaning or rinse water.
- While cleaning, ensure that the condensate pans are cleared of foreign debris. These pans are designed for water only.
- Rinse with hot water, but DO NOT flood.
 - Never introduce water faster than the waste outlet can drain.
- Allow merchandiser to completely dry before resuming operation.
- After cleaning has been completed, remember to restore refrigeration and power back to merchandiser.

Electrical

Merchandiser Electrical Data

The data sheets provide merchandiser electrical data. Refer to the technical data sheets and merchandiser serial plate for electrical information.

Electrical Connections

All wiring must comply with NEC and local codes. All electrical connections including both supply circuits are to be made in the electrical J-Box.



WARNING

— LOCK OUT / TAG OUT —

To avoid serious injury from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.

Field Wiring

Field wiring must be sized for component amperes stamped on the serial plate (refer to page 32 for location). Actual ampere draw may be less than specified.

Identification of Wiring

Leads for all electrical circuits are identified by colored plastic bands. These bands correspond to the color code sticker (shown below) located inside the merchandiser's wireway cover.

Electrical

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times, the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.

STANDARD CASE WIRE COLOR CODE CODIGO DE COLORES DE LOS ALAMBRES PARA LAS VITRINAS ESTANDAR CODE COULEUR POUR FILS DE BOITIER NORMALISE

COLOR DESCRIPTION	DESCRIPCION	DESCRIPTION
 GROUND	TIERRA MASA	MASSE
 ANTI-SWEAT	ANTICONDENSACION	ANTI-SUINTEMENT
 LIGHTS	LUCES	ECLAIRAGE
 RECEPTACLES	ENCHUFES	PRISE DE COURANT
 T-STAT/SOLENOID 230VAC	TERMOSTATO/SOLENOIDE (230VAC)	SOUPAPE A SOLENOID (230 VAC)
 T-STAT/SOLENOID 115VAC	TERMOSTATO/SOLENOIDE (115VAC)	SOUPAPE A SOLENOID (115 VAC)
 T-STAT/SOLENOID 24VAC	TERMOSTATO/SOLENOIDE (24VAC)	SOUPAPE A SOLENOID (24 VAC)
 FAN MOTORS	VENTILADORES	VENTILATEUR
BLUE CONDENSING UNIT	UNIDAD DE CONDENSACION	UNITE DE CONDENSATION

USE COPPER CONDUCTORS ONLY
UTILISEZ LES CONDUCTEURS DE CUIVRE SEULEMENT
UTILICE LOS CONDUCTORES DE COBRE SOLAMENTE
 430-01-0338 R101003

Electrical

Electrical

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment, so all parties are advised.

Initial safety checks shall include:

- a) that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- b) that no live electrical components and wiring are exposed while charging, recovering or purging the system;
- c) that there is continuity of earth bonding.

During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.

Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

- a) Ensure that the apparatus is mounted securely.
- b) Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.

ALWAYS CHECK THE SERIAL PLATE FOR COMPONENT AMPERES


Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.


Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

Replace components only with parts specified by the manufacturer. Other parts can result in the ignition of refrigerant in the atmosphere from a leak.

Power Cord Plug Types




L14-30P
3X45ESPA



CS-6365-C
3X55ESPA
5X7ISPA

*No extension cords to be used with cabled plugs.
Must be a dedicated circuit.


Electrical Component Locations



See page 16 for panel removal

TYA3ECRC						
Replacement Parts List						
Case:	TYA3ECRC3X45ESPA		TYA3ECRC3X55ESPA		TYA3ECRC5X7ISPA	
Part	Part #	Qty	Part #	Qty	Part #	Qty
Fan Motor Assembly 1 - Evaporator	3175954	2	3175954	4	3172579	6
Fan Motor Assembly 2 - Evaporator	3172579	2	3172579	2	NA	
Fan Harness for Evaporator	0443521A	1	0443521A	1	0443521A	1
Evaporator Coil 1	3025174	1	3003281	1	1H77168	1
Evaporator Coil 2	NA		NA		1H77169	1
Control - Dixell XR75	3214216	1	3215860	1	3213801	1
Green NTC Sensor	0334802	2	0334802	2	0334802	2
Switch - On / Off	3212288550	1	3212288550	1	3212288550	1
Power Cord - L14-30P (Locking)	0557599	1	NA		NA	
Power Cord - CS-6365-C (Locking)	NA		3137799	1	3137799	1
Fuse - 15 AMP	125-01-8604	1	125-01-8604	1	125-01-8604	1
LED Driver	3117868	2	3117868	2	3117868	2
LED 36IN 3500K	3181557	1	3181557	1	3181557	4
LED 48IN 3500K	3181558	2	NA		NA	
LED 60IN 3500K	NA		3181559	2	NA	
LED 18IN 3500K	NA		NA		3181555	2

Self-Contained Component Locations



1. Junction Box / Field Tie-in/ Main Power Switch
 2. Condenser Unit
 3. Condenser Fan Motor
 4. Condensation Pan Assy
 5. Compressor
 6. Drain & P-Trap
- See page 16 for panel removal



WARNING

Component parts are specifically chosen for R-454C exposure and therefore non-incendive and non-sparking. Component parts shall be replaced with identical components and servicing shall be done by factory authorized service personnel only, so as to minimize the risk of possible ignition due to incorrect parts or improper service.

Controller Information

Scan the QR code below using your cell phone for controller operating manual. See next few pages for controller setpoints and parameters. Case is shipped with Deli setpoints.

XR75CX Digital Controller for Medium-Low Temperature Refrigeration Applications Installation and Operation Manual



- ①  Open Camera
- ②  iPhone User
Hold the camera up to the QR code
 Android User
Open QR Code Reader app if necessary.
Hold the camera up to the QR code
- ③  Tap the notification to be taken to the destination of the QR code

Controller Information

TYA3ECRC3X45ESPA

		PRGM-TYA3ECRC-3x4.5E-S XR75 R454C		
Parameter	Description	Set Value	Default Value	Function
SEt	Set point	22	-5	Compressor cut out
Hy	Differential	8	2	Compressor cut in is setpoint +differential(Hy). Cut out is setpoint
P2P	Evaporator probe presence	n	y	n=n not present. Defrost stops by time; y = present, defrost stops by temp
P3P	Third probe presence	n	n	n = not present; y = present
o3	Third probe calibration	0	0	Allows to adjust possible offset of the third probe.
P4P	Fourth probe presence	n	n	n = not present; y = present
PbC	Type of probe	CtC	nTC	(nC, CtC) It allows to set the kind of probe used by the instrument: nTC = NTC-EU probe, CtC = NTC-US probe. Set this PbC parameter to CtC to support standard CPC temp sensors - factory default.
CF	Temperature measurement unit	F	°F	°C = Celsius °F = Fahrenheit (CAUTION! When the measurement unit is changed, the setpoint and the values of the parameters Hy, LS, US, ot, ALU and ALL have to be checked and modified if necessary).
rES	Resolution	in	dE	(in = 1°C; dE = 0.1°C) Allows decimal point display.
dFP	Probe selection for defrost	P1	P2	nP = no probe P1 = thermostat probe P2 = evaporator probe P3 = configurable probe P4 = probe on Hot Key plug
dtE	Defrost termination temperature	46	8	(-50 to 50°C; -58 to 122°F) Sets the temperature measured by the evaporator probe, which causes the end of defrost.
idF	Interval between defrost cycles	2	6	(0 to 120 hr) Determines the time interval between the beginning of two defrost cycles.
MdF	(Maximum) length of Defrost	40	30	When P2P = n, (not evaporator probe: timed defrost) it sets the defrost duration, when P2P = y (defrost end based on temperature) it sets the maximum length for defrost.
i2F	Second Digital Input	bAL	EAL	(EAL; bAL; PAL; dor; dEF; ES; AUS; Htr; FAn; HdF; onF) EAL = external alarm: "EA" message is displayed; bAL = serious alarm "CA" message is displayed; PAL = pressure switch alarm, "CA" message is displayed; dor = door switch function; dEF = activation of a defrost cycle; ES = energy saving; AUS = auxiliary relay activation with oA2=AUS; Htr = type of inverting action (cooling or heating); FAn = fan; onF = to switch the controller OFF
did	Digital Input	0	15	(0 to 255 min) Delay between the detection of the external alarm condition and its signaling. When i2F= PAL, it is the interval of time to calculate the number of pressure switch activation
i2P	Second digital input polarity (18-19)	OP	CL	(0 to 15) Number of activation, during the did interval, before signaling an alarm event (i2F=PAL).
oNF	ON/OFF key enabling	oFF	n0	(nU; oFF; ES) nU = disabled; oFF = enabled; ES = not set it

Controller Information

TYA3ECRC3X55ESPA

		PRGM-TYA3ECRC-3x5.5E-S XR75 R454C		
Parameter	Description	Set Value	Default Value	Function
SEt	Set point	22	-5	Compressor cut out
Hy	Differential	8	2	Compressor cut in is setpoint + differential(Hy). Cut out is setpoint
P2P	Evaporator probe presence	n	Y	n=n not present. Defrost stops by time; y = present, defrost stops by temp
P3P	Third probe presence	n	n	n = not present; y = present
o3	Third probe calibration	0	0	Allows to adjust possible offset of the third probe.
P4P	Fourth probe presence	n	n	n = not present; y = present
PbC	Type of probe	CtC	nTC	(nC, CtC) It allows to set the kind of probe used by the instrument: nTC = NTC-EU probe, CtC = NTC-US probe. Set this PbC parameter to CtC to support standard CPC temp sensors - factory default.
CF	Temperature measurement unit	F	°F	°C = Celsius °F = Fahrenheit (CAUTION! When the measurement unit is changed, the setpoint and the values of the parameters Hy, LS, US, ot, ALU and ALL have to be checked and modified if necessary).
rES	Resolution	in	dE	(in = 1°C; dE = 0.1°C) Allows decimal point display.
dFP	Probe selection for defrost	P1	P2	nP = no probe P1 = thermostat probe P2 = evaporator probe P3 = configurable probe P4 = probe on Hot Key plug
dtE	Defrost termination temperature	47	8	(-50 to 50°C; -58 to 122°F) Sets the temperature measured by the evaporator probe, which causes the end of defrost.
idF	Interval between defrost cycles	2	6	(0 to 120 hr) Determines the time interval between the beginning of two defrost cycles.
MdF	(Maximum) length of Defrost	40	30	When P2P = n, (not evaporator probe: timed defrost) it sets the defrost duration, when P2P = y (defrost end based on temperature) it sets the maximum length for defrost.
i2F	Second Digital Input	bAL	EAL	(EAL; bAL; PAL; dor; dEF; ES; AUS; Htr; FAn; HdF; onF) EAL = external alarm: "EA" message is displayed; bAL = serious alarm "CA" message is displayed; PAL = pressure switch alarm, "CA" message is displayed; dor = door switch function; dEF = activation of a defrost cycle; ES = energy saving; AUS = auxiliary relay activation with oA2=AUS; Htr = type of inverting action (cooling or heating); FAn = fan; onF = to switch the controller OFF
did	Digital Input	0	15	(0 to 255 min) Delay between the detection of the external alarm condition and its signaling. When i2F= PAL, it is the interval of time to calculate the number of pressure switch activation
i2P	Second digital input polarity (18-19)	OP	CL	(0 to 15) Number of activation, during the did interval, before signaling an alarm event (i2F=PAL).
oNF	ON/OFF key enabling	oFF	n0	(nU; oFF; ES) nU = disabled; oFF = enabled; ES = not set it

Controller Information

TYA3ECRC5X7ISPA

		PRGM-TY3AECRC-5X7I-S XR75 R454C		
Parameter	Description	Set Value	Default Value	Function
SEt	Set point	23	-5	Compressor cut out
Hy	Differential	8	2	Compressor cut in is setpoint +differential(Hy). Cut out is setpoint
P2P	Evaporator probe presence	y	Y	n=n not present. Defrost stops by time; y = present, defrost stops by temp
P3P	Third probe presence	n	n	n = not present; y = present
o3	Third probe calibration	0	0	Allows to adjust possible offset of the third probe.
P4P	Fourth probe presence	n	n	n = not present; y = present
PbC	Type of probe	CtC	nTC	(nC, CtC) It allows to set the kind of probe used by the instrument: nTC = NTC-EU probe, CtC = NTC-US probe. Set this PbC parameter to CtC to support standard CPC temp sensors - factory default.
CF	Temperature measurement unit	F	°F	°C = Celsius °F = Fahrenheit (CAUTION! When the measurement unit is changed, the setpoint and the values of the parameters Hy, LS, US, ot, ALU and ALL have to be checked and modified if necessary).
rES	Resolution	in	dE	(in = 1°C; dE = 0.1°C) Allows decimal point display.
dFP	Probe selection for defrost	P1	P2	nP = no probe P1 = thermostat probe P2 = evaporator probe P3 = configurable probe P4 = probe on Hot Key plug
dtE	Defrost termination temperature	46	8	(-50 to 50°C; -58 to 122°F) Sets the temperature measured by the evaporator probe, which causes the end of defrost.
idF	Interval between defrost cycles	4	6	(0 to 120 hr) Determines the time interval between the beginning of two defrost cycles.
MdF	(Maximum) length of Defrost	50	30	When P2P = n, (not evaporator probe: timed defrost) it sets the defrost duration, when P2P = y (defrost end based on temperature) it sets the maximum length for defrost.
i2F	Second Digital Input	bAL	EAL	(EAL; bAL; PAL; dor; dEF; ES; AUS; Htr; FAn; HdF; onF) EAL = external alarm: "EA" message is displayed; bAL = serious alarm "CA" message is displayed; PAL = pressure switch alarm, "CA" message is displayed; dor = door switch function; dEF = activation of a defrost cycle; ES = energy saving; AUS = auxiliary relay activation with oA2=AUS; Htr = type of inverting action (cooling or heating); FAn = fan; onF = to switch the controller OFF
did	Digital Input	0	15	(0 to 255 min) Delay between the detection of the external alarm condition and its signaling. When i2F= PAL, it is the interval of time to calculate the number of pressure switch activation
i2P	Second digital input polarity (18-19)	OP	CL	(0 to 15) Number of activation, during the did interval, before signaling an alarm event (i2F=PAL).
oNF	ON/OFF key enabling	oFF	n0	(nU; oFF; ES) nU = disabled; oFF = enabled; ES = not set it

Leak Detection

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

The following leak detection methods are deemed acceptable for all refrigerant systems.

Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity might not be adequate, or might need recalibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed.

NOTE The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine can react with the refrigerant and corrode the copper pipe-work.

NOTE Examples of leak detection fluids are

- bubble method,
- fluorescent method agents.

If a leak is suspected, all naked flames shall be removed/extinguished.


If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

Don't unplug any device if a leak is detected or suspected.

Refrigeration

Refrigerant

The correct type of refrigerant will be stamped on each merchandiser's serial plate. See the following image for serial plate location.



Service Note on Refrigeration Piping

The refrigerant line connections are at the right side of the case (as viewed from the front) under the deck-pans. The merchandiser will have a through-hole in the tub liner that allows lines to exit the merchandiser for liquid and suction line connections. After connections have been made, make certain to seal this outlet thoroughly (if not sealed at factory already). Seal both the inside and outside. We recommend using an expanding polyurethane foam insulation to fill large gaps, then finishing the seal with a Silicone type sealant to prevent any water leaks.



**ATTENTION
INSTALLER**

It is the contractor's responsibility to install case(s) according to local construction and health codes.



CAUTION

Refrigeration lines are under pressure. Refrigerant must be recovered before attempting to make any connections.

Case	R-454C Refrigerant Charge
TYA3ECRC3X45ESPA	4.5 Lbs. (2.04 kg)
TYA3ECRC3X55ESPA	5.0 Lbs. (2.27 kg)
TYA3ECRC5X7ISPA	6.0 Lbs. (2.72 kg)



WARNING

— LOCK OUT / TAG OUT —

To avoid serious injury from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.

Refrigeration

Before Beginning Any Service or Repair:

Use a hand-held R-454C leak detector (“sniffer”) to ensure no R-454C is present in the immediate area, the inside of the display case and the inside of the refrigeration system. R-454C is an odorless refrigerant. Keep the area clear of all customers and non-essential or unauthorized personnel.

Verify that all repair parts are identical models to the ones they are replacing. Do not substitute parts such as motors, switches, relays, heaters, compressors, power supplies or solenoids.

Failure to do so can result in serious injury and property damage. Parts used on cases using flammable refrigerant must meet specific UL certification for non-incendive or non-sparking components.

Use only Hussmann approved parts approved through the Hussmann Performance Parts Website. <https://parts.hussmann.com/>

Brazing must not begin until all R-454C has been cleared from the immediate area — the inside of the displays case and the inside of the refrigeration system.

If a leak is detected, follow store safety procedures. It is the store’s responsibility to have a written safety procedure in place. The safety procedure must comply with all applicable codes such as local fire department’s codes. At minimum, the following actions are required: • Immediately evacuate all persons from the store, and contact the local fire department to advise them that an R-454C leak has occurred. • Call Hussmann and/or a qualified service agent and inform them that an R-454C sensor has detected the presence of R-454C. • Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store.	• The R-454C gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas. • A hand-held R-454C leak detector (“sniffer”) should be used before any repair and/or maintenance is attempted. All repair parts must be identical models to the ones they are replacing. • No open flames, cigarettes or other possible sources of ignition should be used inside the building where the units are located until the qualified service technician and/or local fire department determines that all R-454C has been cleared from the area and from the refrigeration systems.
--	--

Refrigeration

Refrigerant Removal and Evacuation

When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration. The following procedure shall be adhered to:

- a) safely remove refrigerant following local and national regulations;
- b) purge the circuit with inert gas;
- c) evacuate (optional for A2L);
- d) purge with inert gas (optional for A2L);
- e) open the circuit by cutting or brazing.

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum (optional for A2L). This process shall be repeated until no refrigerant is within the system (optional for A2L). When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.

Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.

System Charging

In addition to conventional charging procedures, the following requirements shall be followed.

- a) Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
- b) Cylinders shall be kept in an appropriate position according to the instructions.
- c) Ensure that the REFRIGERATING SYSTEM is earthed prior to charging the system with refrigerant.
- d) Label the system when charging is complete (if not already).
- e) Extreme care shall be taken not to overfill the REFRIGERATING SYSTEM.

Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

A calibrated scale with ± 2 gram accuracy must be used to charge the system. The charge amount is shown on the serial plate. Only R-454C grade refrigerant can be used.

Charge value should be as shown on page 32. When connecting hoses between the refrigeration system, manifold gauges, and refrigerant cylinder, ensure that the connections are secure and there are no potential sources of ignition nearby. Ensure that contamination of different refrigerants does not occur when using charging equipment.

Refrigeration

Refrigerant Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e., special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, FLAMMABLE REFRIGERANTS. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that FLAMMABLE REFRIGERANT does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

1. Tap system with line tap valves, attaching gauges to the high and low sides of the system.



**refrigeration
line tapping
valve**

2. Connect hose to an evacuated recovery tank. Open refrigeration gauges and recovery tank.

3. With the suction valve in vacuum, the refrigerant will be recovered into the recovery tank.

4. Once recovered, close the tank valve and remove the gauge from the tank and connect nitrogen tank to the system to purge it with nitrogen.

5. Pull vacuum to a minimum of 200 microns or lower.



Refrigeration

Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.

- a) Become familiar with the equipment and its operation.
- b) Isolate the system electrically.
- c) Before attempting the procedure, ensure that:
 - i) mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - ii) all personal protective equipment is available and being used correctly;
 - iii) the recovery process is supervised at all times by a competent person;
 - iv) recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scale before recovery takes place.
- g) Start the recovery machine and operate in accordance with instructions.
- h) Do not overfill cylinders (no more than 80% volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another REFRIGERATING SYSTEM unless it has been cleaned and checked.

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing FLAMMABLE REFRIGERANTS, ensure that there are labels on the equipment stating the equipment contains FLAMMABLE REFRIGERANT.

Water Outlet And Water Seal

The condensate water outlet is located in the center of the merchandiser. The outlet has a factory installed, external water seal.

For self contained models, this water seal drains into the condensate evaporator pan located beneath the merchandiser. Ensure the drain hose is properly trapped, and the drain area is not clogged

NOTE: All lower base panels must be in place when the refrigerator is operating. If not, air-flow from the condenser will be directed over the evaporator pan and defrost water in the pan may overflow.



Troubleshooting

Problem	Possible Cause	Possible Solution
Case temperature is too warm.	Ambient conditions may be affecting the case operation.	Check case position in store. Is the case located near an open door, window, electric fan or air conditioning vent that may cause air currents? Case must be located minimum 15 Ft away from doors or windows. Cases are designed to operate at 55% Relative humidity and a temperature of 75-80°F.
	Discharge air temp is out of spec.	Check evaporator fan operation. Check electrical connections and input voltage.
		Fans are installed backwards. Check airflow direction.
		Fan blades are installed incorrectly. Make sure fan blades have correct pitch and are per specification.
		Check to see that fan plenum is installed correctly. It should not have any gaps.
	Case is in defrost.	Check defrost settings. See Technical Specifications section.
	Product is outside of the load limit area, blocking airflow.	Redistribute product so it does not exceed load limit. There is a sticker on the inside of the case indicating what the maximum load line is. See page 17 for details.
	Coil is freezing over.	Return air is blocked, make sure debris is not blocking the intake section.
		Coil close-offs are not installed. Inspect coil to make sure these parts are on the case.
	Condensing coil or evaporator coil is clogged or dirty.	Clean coil.
Case temperature is too cold.	The t-stat temp is set too low.	Check settings. See Technical Specifications section.
	Ambient conditions may be affecting the case operation.	Check case position in store. Is the case located near an open door, window, electric fan or air conditioning vent that may cause air currents? Case must be located minimum 15 Ft away from doors or windows. Cases are designed to operate at 55% Relative humidity and a temperature of 75-80°F.
Condensation on plex / glass.	Ambient conditions may be affecting the case operation.	Check case position in store. Is the case located near an open door, window, electric fan or air conditioning vent that may cause air currents? Case must be located minimum 15 Ft away from doors or windows. Cases are designed to operate at 55% Relative humidity and a temperature of 75-80°F.

Troubleshooting Cont'd

Problem	Possible Cause	Possible Solution
Water has pooled under case.	Case drain is clogged.	Clear drain.
	PVC drains under case may have a leak.	Repair as needed.
	Case tub has unsealed opening.	Seal as needed.
	If the case is in a line-up, case to case joint is missing or unsealed.	Install case to case joint and seal as needed.
	Evaporator pan is overflowing (if applicable).	Check electrical connection to evaporator pan. Check float assembly, it should move freely up and down the support stem. Clear any debris.
Case is not draining properly.	Case is not level.	Level the case.
	Drain screen is plugged.	Clean drain screen and remove any debris.
	Drain or P-trap is clogged.	Clear any debris.
Frost or ice on evaporator coil.	Evaporator fans are not functioning.	Check electrical connections.
	Defrost clock is not functioning.	Case should be serviced by a qualified service technician.
	Coil is freezing over.	Return air is blocked, make sure debris is not blocking the intake section.
		Coil close-offs are not installed. Inspect coil to make sure these parts are on the case.

Service

Plex can become scratched with daily use. With a few supplies, you can remove most of the scratches.

Step 1

Clean the surface around the scratched area to remove any grime, grease or dirt. Make a soapy mixture of warm water and mild liquid detergent and use a clean, soft rag to wash down the area. Rinse the Plex with warm water and wipe it dry with a clean, soft rag.

Step 2

Run your fingertips across the surface to determine how severe the scratches are. If your fingernails catch as they move across the surface, the scratches are heavy -- skip to Step 6. If you can barely feel the scratches, they are light surface scratches and can usually be rubbed and buffed out.

Step 3

Apply a small amount of mild abrasive polishing compound to the scratched area with a clean, soft rag. With constant pressure, move your hand in a circular motion until the scratches become hard to see. This may take several minutes and you may need to apply more compound. Continue the rubbing process until the scratches are no longer visible.

Step 4

Wipe off the compound with a clean, soft rag. If you can still see the scratches, submerge a sheet of 800-grit sandpaper in a bucket of water, remove it and then fold into a workable size.

Rub the surface using a circular motion. Keep enough moisture on the paper to avoid overheating the Plex. Once the scratches become hard to see, repeat the process with finer, 1200-grit sandpaper.

Step 5

Buff the Plex with metal polish to bring back the shine. Apply the polish with a clean, soft rag and move your hand in a circular motion to buff the area to complete your repair of lightly scratched Plex. Several applications of polish may be needed to fully restore the shine.

Step 6 (for heavy scratches only)

Submerge a sheet of 600-grit sandpaper in a bucket of water to begin the process of handling heavy scratches. Remove the sandpaper and fold it into a workable size. With constant pressure, rub the surface using a circular motion. Keep enough moisture on the paper to avoid overheating the Plex. Continue wet-sanding for two to three minutes.

Step 7 (for heavy scratches only)

Repeat the process with 800-grit sandpaper followed by 1200-grit sandpaper. Wipe the surface dry with a clean, soft rag. Follow the instructions in Step 5 to buff the Plex and restore the shine.

Step 8

Wipe off the compound with a clean, soft rag.

Service cont'd

Evaporator Fan Replacement.



Disconnect electrical power before starting motor replacement. Lift and remove Deck Pans (1) to access Fan Plenum (3). The Fan Plenum may be removed from the case for easier access if needed. Turn Fan Plenum over to access Fan Motor Assy (5). Remove Screws (4) from top of Fan Motor Assy. Disconnect motor connection and remove Fan Motor Assy.

Please be aware that the 3X4.5 and 3X5.5 units have 2 different motors. Please ensure you replace the correct one based on the position on the unit. See images on page 41.

1. Deck Pan
2. Fan Harness
3. Fan Plenum
4. Screw
5. Fan Motor Assy

See Images Below (5X7 model shown).


To install, reverse order from above.



Service cont'd


3175954
FAN ASM-12W 200NM 28 1250RPM
QTY: 2

3X4.5



3175954
FAN ASM-12W 200NM 28 1250RPM
QTY: 4

3X5.5




Service cont'd

LED Driver Replacement



Disconnect electrical power before starting LED Driver replacement. Remove Lower Side Panel to access Junction Box. Junction Box cover needs to be removed to access the LED driver, remove screws (red arrows indicate locations). Disconnect LED Driver wires from connector/blocks/harnesses (noting existing locations). Refer to wiring diagram for reference. Wiring diagram can be found at www.Hussmann.com. Search for "TYA3ECRC" and scroll to "Datasheet" link. Remove screws holding LED Driver (red arrows indicate locations) and replace. Reverse order to connect LED Driver and install all covers.

See Image Below.

6. Outer Panel
7. Junction Box / Field Tie-in
8. LED Driver



Service cont'd



Service cont'd

Every working procedure that affects safety means shall only be carried out by competent persons.

Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized.

The following checks shall be applied to installations using flammable refrigerants:

- a) The actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed.
- b) The ventilation machinery and outlets are operating adequately and are not obstructed.
- c) If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant.
- d) Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected.
- e) Refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of material which are inherently resistant to being corroded or are suitably protected against being so corroded.

Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed.

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e., nonsparking, adequately sealed, or intrinsically safe.

If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available on hand. A dry chemical or CO₂ fire extinguisher should be adjacent to the charging area.


No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment shall be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

WARNING

— LOCK OUT / TAG OUT —

To avoid serious injury from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.



HUSSmann®

**To obtain warranty information
or other support, contact your
Hussmann representative.
Please include the model and
serial number of the product.**

**Hussmann Warranty / Technical Assistance
(800) 592-2060**

Hussmann Corporation, Corporate Headquarters: Bridgeton, Missouri 63044 2014