

Vertical Air Merchandiser Custom Panel Installation Instructions Guide



1. Unscrew all screws from the top of the panel frame



2. Unscrew the left corner screw from the bottom of the panel frame

Vertical Air Merchandiser Custom Panel Installation Instructions Guide



3. Open panel frame and gently push the panel left
4. Pull out the panel on the left side



5. Replace the old panel with the new panel by sliding it in on the left and pushing it all the way to the right



6. Reattach the bottom left screw and all of the top screws