



Electric Cheese Melters

Base Models:

#177CHSME23IM

177CHSME24IA

177CHSME32IM

Warning:

Improper installation, adjustment, alteration, service, or maintenance can cause property damage, injury, or death. Read the installation, operating, and maintenance Instructions thoroughly before installing or servicing this equipment.

For Your Safety:

Do not store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other appliance.

Note:

Please read and keep these instructions. Indoor use only.

Table of Contents

Wiring Diagram	3
Exploded Parts Diagram	4

NOTE: Visit www.AvantcoEquipment.com for questions about warranty and replacement parts.

#177CHSME24IA




#177CHSME23IM & #177CHSME32IM




CONFORMS TO NSF/ANSI STD. 4
CONFORMS TO UL STD. UL-197
CONFORMS TO CAN/CSA-C22.2 NO. 109

Wiring Diagrams


177CHSME23IM, 177CHSME32IM



177CHSME24IA



Exploded Parts Diagram



#	Description	Pcs
1	Top Body	1
2	Heater Cover	1
3	Heater	1
4	Heater Fixer	3
5	Left Board	1
6	Crumb Tray	1
7	Grill Grid	1
8	Handle of Grill Grid	2

#	Description	Pcs
9	Body	1
10	Right Fixer of Heater	1
11	Terminal Block	1
12	Plug & Power Cord	1
13	Fixer of Power Cord	1
14	Right Board	1
15	Feet	4
16	Timer	1

#	Description	Pcs
17	Energy Regulator	1
18	Knob Base of Timer	1
19	Knob Base of Energy Regulator	1
20	Knob of Energy Regulator	1
21	Indicator	1
22	Knob of Timer	1