






WARMER ASSEMBLIES

ITEM	PART NO.	QTY.	DESCRIPTION
1	03652.0000	2	Warmer Assy, 100W 120V (Includes items 2 thru 5)
	02817.0000	2	Warmer Assy, 100W 220V (Includes items 2 thru 5)
	03668.0000	1	Warmer Assy, 130W 120V (Model SDB)(Includes items 2 thru 5)
	01303.0000	6	Screw #4-40 x .50"
	00916.0000	6	Fastener, "J" Type #4-40
2	03656.0000	2	Dish
3	01227.0000	2	Warmer Element, 100W 120V
	01951.0000	2	Warmer Element, 100W 220V
	01225.0000	1	Warmer Element, 130W 120V (Model SDB)
4	13042.0001	2	Spacer
5	05212.0000	2	Plate
	00970.0000	4	Nut, KEPS #8-32
6	03697.0000	1	Warmer Assy, 100W 120V (Includes items 7 thru 10)
	02817.0000	1	Warmer Assy, 100W 220V (Includes items 7 thru 10)
	03696.0000	1	Warmer Assy, 130W 120V (Includes items 7 thru 10)
	01303.0000	3	Screw #4-40 x .50"
	00916.0000	3	Fastener, "J" Type #4-40
7	03656.0000	1	Dish
8	01143.0000	1	Warmer Element, 100W 120V
	01951.0000	1	Warmer Element, 100W 220V
	01142.0000	1	Warmer Element, 130W 120V
9	13042.0001	1	Spacer
10	05212.0000	1	Plate
	00970.0000	2	Nut, KEPS #8-32