



CART/TROLLEY FOR ZEPHYR COTTON CANDY MACHINE




CONTENTS



DO NOT TIGHTEN SCREWS UNTIL FULLY ASSEMBLED


1 ATTACH SIDE PANELS

- Attach the **side panel A** to the **side panel with holes at the bottom** with **short screws and nuts**.



2 ASSEMBLE THE STORAGE COMPARTMENT


- Attach the **assembled side panel** and **side panel with holes at the top** to the **top shelf** and **bottom shelf** with **short screws**.
- Attach the **front panel** to the cart with **screws**.
Do not attach the screws on leg side.
- Place the **top stainless shelf** on top.



DO NOT TIGHTEN SCREWS UNTIL FULLY ASSEMBLED


3 ATTACH THE SIDE SHELF

- Attach the **side panel B**, **side panel C**, and **side panel D** to the cart with **short screws**.
- In the middle attach the **side shelf cross bars** with **short screws** and **nuts**.
- Place on **side stainless top**.




4 ATTACH WHEELS AND LEGS

- Flip the cart upside down.
- Slide the **axle** through the **side shelf**.
- Attach the **wheels** onto the **axle** and secure with **axle pins**.
- Slide the **legs** through the **bottom shelf** and align holes and secure with **long screws** and **nuts**.
- Secure the **front panel** to the **leg** with **short screws**.



5 ATTACH THE HANDLE

- Attach the **handle** to the **side panel** and secure with **screws** and **nuts**.



6 FINAL CHECK

- Stand the cart upright on a level surface/floor.
- Ensure wheels and legs are touching the floor evenly.
- Firmly tighten all screws to ensure they are secure.

