



Stainless Steel Mandoline with 5-Piece Interchangeable Blade Set

Use and Care Guide

08/2026

Hazard Statements



WARNING
To prevent
personal injury.



WARNING
Cut hazards.



WARNING
Wear cut-resistant gloves.

Do Not Use if Damaged: Product should not be used if damage is found. Contact an authorized service center.

Warning: Mandoline blades are sharp. Always wear cut-resistant gloves when changing, removing, and storing the mandoline.

Caution: Store mandoline indoors and away from moisture when not in use to maintain sharpness and prevent rust.

Caution: Dispose of blades and sharp accessories immediately, in a puncture-resistant container, if damaged or broken.

Protect Hands: Keep fingers away from the blades at all times.

Handle Mandoline with Care: Avoid direct contact with razor-sharp edges during attachment changes or cleaning.

Store Safely: Store mandoline indoors and keep it dry to prevent rust.

Initial Setup

Unboxing: Carefully remove packaging. Avoid using sharp tools that could damage the unit.

- Do not force a box cutter or knife through packaging, as it may damage the product or accessories.
- Ensure you do not damage the product or its components when removing it from the packaging.
- If any damage is present, contact customer service immediately.

Cleaning

Warning: Mandoline blades are sharp. Always wear cut-resistant gloves when changing, removing, and storing the mandoline.

Initial Cleaning

- **Clean Before First Use:** Wash assembly with warm, soapy water. Rinse thoroughly to remove protective films and oils.
- **Dry Components:** Air dry or towel dry all parts completely.

Cleaning After Use

- **Prepare for Cleaning:** Food acids will make the blade dull and corrode the metal. Always clean before and after use.
- **Clean Components:** Wipe or scrub all removed parts with detergent and sanitizer.
- **Wash and Rinse Parts:** Wash components thoroughly. Rinse with clean water.
- **Dry Components:** Air dry or towel dry all parts completely.

Stainless Steel Mandoline with 5-Piece Interchangeable Blade Set

Use and Care Guide




Assembly

Warning: Mandoline blades are sharp. Always wear cut-resistant gloves when changing, removing, and storing the mandoline.

Parts

Included:

- A. Stainless steel mandoline
- B. Folding legs with non-slip grip
- C. Stainless steel straight blade for slicing
- D. Stainless steel serrated blade for crinkle and waffle cuts
- E. Stainless steel julienne blades (10 teeth, 14 teeth, 21 teeth)
- F. Safety holder to hold fruits and vegetables while cutting



Stainless Steel Mandoline with 5-Piece Interchangeable Blade Set Use and Care Guide



Operation


Warning: Mandoline blades are sharp. Always wear cut-resistant gloves when changing, removing, and storing the mandoline.

Intended Use: Intended for slicing food products.

Inspect Before Use: Verify the mandoline is clean. Check that the mandoline is not damaged (broken attachments, cracked frame, or missing components). Do not use if damage is found.

Position Mandoline: Place flat on a cutting surface or across a container. Do not extend the support leg when used over a bowl.

Food Size: Cut fruits and vegetables until they fit the safety holder.




CRINKLE AND WAFFLE CUTS

Serrated Blade: Insert the blade from the side while holding the handle.

Crinkle Cuts: Make a single pass across the blade.

Waffle Cuts: Set the upper plate for thin slices. Make one pass, rotate food or safety holder 90 degrees, and make a second pass.



Adjust Slice Thickness: Loosen the two upper tightening knobs to allow the platform to move.



Set Desired Thickness: Slide the platform up or down to achieve the desired slice thickness.

Secure Platform: Tighten the knobs to lock the platform in place.

Avoid Over-Tightening: Do not over tighten the knobs. Only slight resistance is required.

Cut Thickness: The gap between the upper plate and the blade indicates the thickness of the cut.

Maintain Alignment: The upper plate remains parallel at all times to provide consistent thickness adjustment.



JULIENNE CUTS

Slicing Blade: Insert the straight slicing blade first.

Julienne Blade: Insert the selected julienne blade fully into the slot by the handle.

Set Thickness: Adjust the platform to the desired cut size.

Cut Lengthwise: Place food lengthwise in the safety holder and slide evenly across the blade.

Stainless Steel Mandoline with 5-Piece Interchangeable Blade Set

Use and Care Guide



Maintenance

Warning: The cutting assembly is sharp. Always wear cut-resistant gloves when changing, removing, and storing the cutting assembly.

Hand Washing: This product can be washed in a dishwasher, but hand washing extends product life.

Straight Blade: Sharpen blades as they become dull to reduce injury risk.

Serrated Blade: Have serrated blades sharpened by a cutlery specialist.