

COPOLYESTER DRINKWARE



Due to its chemical composition, copolyester drinkware requires proper care to retain its value and beauty throughout its service life.

FIRST USE

- Before first use, wash drinkware in hot water using mild detergent (rinse and dry before storing)

HANDLING

- After clearing from tables, immediately empty any remaining liquids and debris
- **Avoid using abrasive materials** (steel wool, metal scrapers, scouring pads, stiff brushes) to remove debris

PRE-SOAKING

- **Soak in 140–160°F water** with chlorine-free, acid-free, non-abrasive detergent for 10–20 minutes

WASHING

- **Consult with your chemical supplier to ensure use of recommended, plastic-safe products for best results with your dishwasher and water conditions**
- Wash as soon as possible, using appropriately-sized glass racks
- Do not use peg racks or stiff glass-washer brushes, which may cause scratching



DRYING (afterwash)

BEST PRACTICES

- Remove residual water by drying with a soft cloth or towel to prevent water spotting and mineral build-up
- Store in a dry area away from humidity and grease
- To extend the life of your product, **minimize contact with sunscreen by rinsing or cleaning immediately after contact** (exposure to spray sunscreen at high temperatures can cause clouding or staining)
- **Never leave copolyester drinkware unwashed for long periods of time**, as acidic or salty foods and beverages may cause staining or corrosion
- Soak in a 10% oxygenated bleach/water solution for 8-24 hours to remove stains

