



Installation/User Guide



Coffee Rectangle LED Sign

PACKAGE CONTENTS

- (1) Coffee Sign
- (1) Power Adaptor
- (1) Hanging Hardware Kit
 - (2) Silver hanging chains

OPERATION

- All sign functions are controlled by the gold cord located on the bottom of the sign.
- To turn the sign On/Off, pull the cord located on the bottom of the sign. Each time the cord is pulled, the sign will change functions.



POWER INPUT
Located on side of sign

**ON/OFF &
EFFECT CONTROL
CORD**

INSTALLATION

- Mount the sign in an area where it can be easily seen by the customer with no obstructions. You will need easy access to an electrical outlet and a clear area in the window for the mounting hardware.
- Keep in mind your need to see out through the window, and the needs of customers and security to see in.



SIGN CLEANING

- The sign should be periodically cleaned to prevent dust build up.
- To clean the sign, use water or any non-industrial common household glass cleaner such as Noble Chemical's 1 Quart Reflect Glass Cleaner - Item #147REFLECTQT
- Spray or moisten a towel lightly and wipe off dust. Do not spray cleaner directly onto the sign, or soak the sign in liquid.

CAUTION

- INDOOR USE ONLY - Do not install the sign and power supply near areas of humidity and heat.
- PREVENT TAMPERING & DESTRUCTION - Do not install the sign where unauthorized personnel can reach, where it blocks entrances and emergency exits, where one needs fast access to or where it blocks air conditioning & heating ducts for air flow.