


Turn On And Preheat The Oven

Alto-Shaam recommends preheating the Combitherm® before cooking.

1. Push the **Power** button.  or  Green light will appear while oven is booting up.
2. Choose a **Mode**.  Steam  Combi  Convection
3. Push the **Oven Temperature** button. 
4. Adjust the temperature with arrow buttons. 
5. Push the **Cook Time** button. 
6. Adjust the time with arrow buttons. 
7. Push the **Start/Stop** button. 
8. Preheat the oven before loading food.

To Cook Manually By Probe

1. Choose a **Mode**.  Steam  Combi  Convection
2. Push the **Oven Temperature** button; adjust the temperature using the arrow buttons.  
3. Push the **Probe Temperature** button; adjust the temperature using the arrow buttons.  
4. Load food into oven and insert probe into food.
5. Push the **Start/Stop** button. 



To Cook Manually By Time

1. Choose a **Mode**.  Steam  Combi  Convection
2. Push the **Oven Temperature** button; adjust temperature using the arrow buttons.  
3. Push the **Cook Time** button; adjust time using the arrow buttons.  
4. Load food into oven.
5. Push the **Start/Stop** button. 

To Clean The Oven

1. Push the **Cleaning** button. 
 2. Insert appropriate number of CombiClean® tabs as directed by the LED Screen (CLn4 appears).
 3. Close the oven door and push the **Start/Stop** button. 
- If oven is too hot to proceed, **dOOr** will display on the LED screen. Open the oven door to allow the oven to cool. When the oven is finished cooling, begin the cleaning procedure again.
4. Oven beeps when it is done cleaning. Leave door slightly ajar when cleaning is finished.

NOTE: TO SHUT THE OVEN OFF, PRESS AND HOLD  FOR FIVE SECONDS. THE RED LIGHT WILL APPEAR INDICATING THAT THE OVEN WILL BEGIN THE SHUT DOWN PROCESS.

TO FORCE SHUT DOWN IN THE RARE EVENT THE CONTROL LOCKS UP, PRESS AND HOLD  FOR TEN SECONDS.

ALTO-SHAAM®