

W-Series L-Bar Spare Parts Diagram




Figure 1. Spare Parts Diagram

W-SERIES L-BAR SPARE PARTS DIAGRAM

Item	Part #	Description	Comments
1		Upper Bracket	specify model # when ordering
2		Shaft	specify model # when ordering
3	WHL-3	Bearing-PHS12	
4		Ring / E-Clip	
5		Bushing / Nut	
6	WHL-6	Spring/Arm Set (2pc set)	
7	WHL-7	Screw 1/4, Hex/Black	
7a	WHA-7	Spring, Upper Bracket	
8	WHL-8	Spring (for Hook Pin)	
9	WHL-9	L-Type Fixed Plate	
10		Ceramic 90° Gen 1.0	
10a		Ceramic 90° Gen 2.0	Includes #9, 10a
11		Ceramic Bracket	specify model # when ordering
12	WHL-12	Ceramic	W-350L - 32pcs W-500L - 43pcs W-650L - 54pcs
13	HE-1420-W-350L HE-2026-W-500L HE-2631-W-650L	Heating Wire 3.2*0.32	specify model # when ordering
14	TA-14+20 TA-20+26 TA-26+31	PTFE Adhesive	specify model # when ordering
15	WHL-15	Hook Pin for Heating Wire	
15a	SHA-WHL	Spring Hook Assembly	Includes #8, 15, 16
16	WHL-16	Insulated Bushing	
17	WHL-17	Fixed Plate	
18	WHL-18	Fixed Bracket	
19	WHL-19	Handle	
20	SRSet-model#	Silicone Rubber (2pc set)	specify model # when ordering
21		Silicon Bracket (2pc set)	specify model # when ordering
22		Upper Cover	
23	TRNS-model#	Transformer	specify model # when ordering
24		Roller for EVA & PE Roller	
25	WHL-25	Film Separator	
26	WHL-26	Washer For Roller / White Silicone	
27	WHL-27	Eva Roller (L) Foam	
28	WHL-28	Eva Roller (S) Foam	
29	WHL-29	PE Roller w/Needle	
29a	WHL-2a	Eva Roller L(27) and S(28) + PE Roller w/Needle (29)	
30		Needle in Perforator	

Figure 2. Spare Parts Diagram List (Table 1 of 2)

W-SERIES L-BAR SPARE PARTS DIAGRAM

Item	Part #	Description	Comments
31	WHL-31	Bracket	
32	WHL-32	Spring for #31 Bracket	
33		Bracket for Film Holder	
34		Transformer Holder	
35		Heat Gun Holder	
36		Heat Gun Fixed Bracket	
37	WHI-13	Power Socket for Heat Gun	
38		Heat Gun (Not Included)	Model: HG-1-CY
39	WHL-39	Power Cord	
40		Body	
41		Screw M12 to adjust Lever	
42	MSW-WHF	Microswitch	
43		Rubber Foot	
44		Adjusting Frame for Working Plate	
45		Plate	
46	T-WHL	Control Panel / Timer	Includes #46, 47, 48, 49, 50, 51, 52
47	WHA-33	Led Lamp	
48	WHI-2	Power Switch, 3P, Red	
49	WHA-30	Knob	
50	WHI-11b	Circuit Breaker, 10A	
51	T-WHL	PC Board for Timer	Includes #46, 47, 48, 49, 50, 51, 52
52	WHA-36	Variable Resistor	
53		Screw for Working Plate	
54		Working Plate / Adjustable	
55	WHL-55	Magnetic switch S-P-11	
56		Box	
57		Roller, Complete w/ Bearings for Holding Shrink Film	specify model # when ordering

Figure 3. Spare Parts Diagram List (Table 2 of 2)