




EP-3560

Lifter Device (standard version w/ tool mast)

control instructions

IT IS THE RESPONSIBILITY OF THE CUSTOMER TO ENSURE THAT
ALL OPERATORS AND SERVICE PERSONNEL HAVE FULLY READ
AND UNDERSTOOD THIS DOCUMENT

**READ ALL INSTRUCTIONS BEFORE OPERATING TOOLS.
FAILURE TO FOLLOW ANY OF THESE GUIDELINES COULD
RESULT IN SERIOUS OR FATAL INJURY**



P (847) 735-8105 | F (847) 735-8297
sales@encorepack.com | www.encorepack.com



201 Park Avenue, Lake Villa, IL 60046
P.O. Box 595, Winnetka, IL 60093



IMPORTANT



PLEASE READ PRIOR TO USAGE


To ensure operator safety, it is important that all personnel use proper safety and handling procedures. This safety booklet is designed to educate operators on the safe use of the EP-3560 Lifter Device (standard version w/ tool mast). All personnel must read and understand this booklet prior to using this product. Failure to follow any of the recommendations in this pamphlet can result in serious injury or death.

READ PRODUCT SAFETY LABELS

- Read and understand all safety labels on the tool
 - Replace all damaged or missing labels
- INSPECT THE TOOL DAILY AND REPLACE ALL WORN OR BROKEN PARTS. LUBRICATE ALL MOVING PARTS DAILY.

READ THE INSTRUCTIONS

Before operating this tool, read, and understand all safety, operation, and maintenance information provided in the manual which is packaged with the tool. If you do not have a manual or need extra copies, please contact your Sales Representative.




Terms & Conditions are found on our website: <https://www.encorepack.com/legal.php>

Please read our Terms & Conditions carefully prior to using or obtaining any materials, information products or services of **Encore Packaging LLC**, an Illinois limited liability company with a place of business at **201 Park Avenue, Lake Villa, IL 60046**.

P (847) 735-8105 | F (847) 735-8297  201 Park Avenue, Lake Villa, IL 60046
sales@encorepack.com | www.encorepack.com P.O. Box 595, Winnetka, IL 60093

OPERATION GUIDE


PLEASE VIEW PRIOR TO USAGE



FRONT VIEW

OPERATIONS GUIDE



- | | |
|---|---|
| 1 | Install charged battery into slot. |
| 2 | Turn on ON/OFF Switch using provided key. |
| 3 | Using the joystick, lift coil and lower into dispenser. |




SIDE VIEW

MOTOR CONTROLS (BACK)

- | | |
|---|------------------------------------|
| 1 | Battery Slot |
| 2 | ON/OFF Switch |
| 3 | UP/DOWN Joystick for Lifter Device |



EP-3560 **PART LIST**



06/14/24 REV C

EP-3560 **PARTS LIST**

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	E3560-01	Base	1
2	EP-3075	Floor Mount with Cutter	1
3	E6420-12	Hex Head Bolt	8
4	E5960-04	Washer	22
5	E3065-19	3/8" Nylock Hex Nut	10
6	E3080-15	Cart Tray	1
7	E3560-02	Wheel	2
8	E6748-02-Q	BHCS, 10-24 X 7/8	8
9	E3550-02-F	10-24 Nylock Nut	8
10	E6220-04	3" Caster*	4
11	E800-06-D	Flat Washer	4
12	E6420-03-G	M12 Nylock Nut	4
13	E3560-05	Mounting Plate	1
14	E3560-18	Electric Enclosure	1
15	E3560-07	Adapter	2
16	E3500-09	HHS, 3/8"-16 X 3	4
17	E3560-03	Suspension Beam	1
18	E3550-04	Washer	1
19	E3550-06	M12 Lock Washer	1
20	E3560-04	Trolley	1
21	E3550-07	M12 X 25mm	1

06/17/24 REV C



P (847) 735-8105 | F (847) 735-8297
sales@encorepack.com | www.encorepack.com



201 Park Avenue, Lake Villa, IL 60046
P.O. Box 595, Winnetka, IL 60093