

Cleaning Instructions

Classic Plush mats can be commercially laundered (see laundering instructions) or cleaned using the instructions below:

- Vacuum regularly (daily in high-traffic commercial areas; weekly in lower-traffic areas)
- Extract or hose off as needed to remove heavy soil/debris
- Hang mat to dry

Always make sure the mat is dry before placing it back in service.

Laundering Instructions

Classic Plush mats that are backed with nitrile rubber can be commercially laundered. Proper laundering will prolong the life of the mat by preventing the buildup of soil and soap residue. For heavy soil, increase temperature to max 140 degrees F (60 degrees C). Break should not exceed pH of 9.5; use low pH non-ionic detergents.

1. Flush 2-3 minutes, medium water level, 120 degrees F (49 degrees C)
2. Flush (optional) 2-3 minutes, medium water level, 120 degrees F (49 degrees C)
3. Break 2-3 minutes, high water level, 120 degrees F (49 degrees C)
4. Rinse 2 minutes, high water level, cold
5. Rinse 2 minutes, high water level, cold
6. Extract (low speed) 1-2 minutes
7. Shake out (rotate wheel at wash speed with drain open) 1 minute
8. Extract (low speed) 3-5 minutes
9. Dry 5-10 minutes, 180 degrees F (82 degrees C) basket temp.
10. Cool down 5 minutes
11. Lay mats flat following removal from washer or dryer. Allow to cool before rolling.

Do not over-dry mats; basket temperature of dryer should not exceed 180 degrees F (82 degrees C).

If mats are not dried, final rinse can be increased to 140 degrees F (60 degrees C). This will reduce moisture retention following extraction.