

Use & Care Guide

SEATING & TABLES



LANCASTER[™]
TABLE & SEATING

METAL FURNITURE



CRITICAL INFORMATION

- **Chair and Stool Safety:** Keep all four legs on the ground. Do not shake or sway.
- **Table Safety:** Do not sit, stand, shake, lean, jump, or climb on tables.
- **Prevent Misuse:** Do not use chairs or tables as support when leaning or standing.



HAZARD STATEMENTS

USER SAFETY

Warning—to prevent personal injury.

WARNING—CHILD SUPERVISION

- Unsupervised children may misuse the product, leading to potential injury or damage to the product.
- Children should be supervised to ensure that they do not play with the product.
- Do not allow children to use or play with the product without proper supervision.

WARNING—RESTRICTED USE

- This product is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.
- Avoid unsupervised use by individuals without adequate instruction or capability.
- Improper use by unauthorized individuals may result in personal injury or equipment damage.
- **Do Not Use if Damaged:** Product should not be used if damage is found. Contact an authorized service center.
- **Keep Labels:** Do not remove any safety labels.



Use & Care Guide

SEATING & TABLES



LANCASTER[™]
TABLE & SEATING

METAL FURNITURE



ASSEMBLY

- **Assembling Product:** Have a qualified person complete assembly using the instructions provided with the product, if applicable.
- **Chair and Stool Safety:** Keep all four legs on the ground. Do not shake or sway.
- **Table Safety:** Do not sit, stand, shake, lean, jump, or climb on tables.
- **Prevent Misuse:** Do not use chairs or tables as support when leaning or standing.



INITIAL SETUP

- **Inspect the Packaging:** Examine the product's packaging for any signs of damage that may have occurred during shipping.
- **Unboxing:** Open the packaging with care.
 - Do not press a box cutter or knife through packaging, as it may damage the product or accessories.
 - Ensure you do not damage the product or its components when removing it from the packaging.
 - If any damage is present, contact customer service immediately.
- **Check Components:** Examine welds and fasteners for damage before use. Ensure all legs sit flat on the ground.



CLEANING & MAINTENANCE

GENERAL CLEANING

- **Follow Warranty Guidelines:** Damage from misuse or improper cleaning may not be covered under warranty.
- **Avoid Harsh Pads or Cleaners:** Avoid abrasive materials (scrubber pads, steel wool, etc.) or harsh cleaners (ammonia, bleach, acetone, glass cleaners, etc.).
- **Test Cleaners:** Test new cleaners on a hidden area before use. Always use a cleaner that is marked safe for the material being cleaned.

FABRIC & VINYL SEATING

- **Fabric and Vinyl Cushions:** Use a vacuum cleaner to remove dust and dirt.
- **Fabric Cleaning:** Use a detergent that is safe for fabric cleaning.
- **Vinyl Cleaning:** Use a multi-purpose cleaner safe for vinyl furniture.
- **Clean Spills Promptly:** Use a soft, clean cloth to clean spills.
- **Removable Fabric Covers:** Check the machine-wash label. Spot clean only if washing is not allowed.

WOODEN SEATS

- **Clean Weekly:** Use a clean, soft cloth. Clean in the direction of the wood grain to prevent scratching.
- **Clean with Mild Soap:** Clean with mild soap and a damp cloth. Wipe down with a dry, clean cloth.
- **Ensure Wood is Fully Dry:** Allow wood to dry completely before use to prevent damage.

