

Moist-Heat Hot Dog Bun Warmer Kit

1. Carefully unpackage unit and ensure it is placed on a level surface.
2. Remove wire grate located inside the warmer's drawer and pour the recommended amount of water into the pan. Then, place the grate back inside the pan.
3. Recommended water amounts:
 - 32-bun capacity unit (177BW32M): 2 cups of water in full-sized pan.
 - 48-bun capacity unit (177BW48M): 2 cups of water in full-sized pan and 1 cup of water in half-sized pan.
4. Once the wire grates are in place and there's water in the pan(s), adjust the temperature control dial to the max temperature to preheat the unit. This should take about 15–30 minutes.
5. Once the unit is preheated, insert your desired number of buns up until the unit's capacity and lower the temperature to 135 degrees Fahrenheit.
6. Once the unit is loaded, close the drawer and allow the unit to warm the buns in a moist environment allowing for lengthy storage times without worry of drying out.
7. If using for an extended period of time, make sure to top off water as necessary.

Note: Humidity level depends on the amount of water added to the pan as well as the temperature of the unit.