

NESPRESSO MOMENTO 100 CLEANING INSTRUCTIONS

END OF DAY



1 With machine on, remove water tank, empty, clean with a cloth and rinse with water. Refill water tank, attach lid and place back into the machine.



2 Empty and clean used-capsule container and place back into the machine. Make sure to recycle used capsules using a **Nespresso** recycling bag.



3 Remove drip tray and grid, empty drip tray, rinse with water and dry with a cloth. If necessary, use a small brush and dish soap to clean residual coffee traces. Place drip tray with grid back into the machine.



4 Remove coffee outlet cover — be careful, hot water might drip. Rinse with water, dry with a cloth and insert back into the machine.



5 Clean machine surface with a soft cloth. Be careful, cup warmer on top might be hot.

