

# Touch Free Dispensing System Instructions


Please carefully read all instructions before installing and using the dispenser.

## Installing the Dispenser

Do not install in locations where dispenser may be exposed to wet environments, such as showers or areas where walls are washed down.


### Tape Installation

Use only on smooth, dry surfaces




### Fastener Installation


Use on rough or smooth surfaces



## Battery Installation



## Loading Refill into the Dispenser



## Dispenser Use



## Cleaning and Maintenance

Clean exterior surfaces of the dispenser using warm water and mild soap.  
**DO NOT USE ABRASIVE CLEANERS.**  
Dry with a soft cloth

## Troubleshooting

### No Dispense, Motor Does Not Run

- Hands are not directly beneath sensor
- No refill is loaded
- Incorrect refill is loaded
- Batteries are not loaded, or are loaded incorrectly

### No Dispense, Motor Runs

- Refill is empty or is loaded improperly
- Refill pump is not primed

Specifications per UL 8800-4  
Type B Approved  
Not suitable for use in the presence of a flammable atmosphere

Definition of Symbols



Type B Approved



Attention, consult accompanying documents



UL LISTED  
EVALUATED TO UL 8800-4  
TYPE B APPROVED FOR USE IN  
FLAMMABLE ATMOSPHERES

2700-951