

BUNN®

BEVERAGE DISPENSING

USE & CARE INSTRUCTIONS for ThermoFresh® SERVER with DIGITAL SIGHT GAUGE



STEP 1

The Server Cover needs to be removed to fill the Server when brewing from a Bunn-O-Matic® Dual TF DBC or Single TF DBC or ICB coffee brewer.



STEP 2

When proper precautions are followed, 1.0 up to 1.5 gallons of coffee may be brewed directly into the server and then transported to a remote serving location. The server must be placed on a sturdy counter or shelf.



STEP 3

Place a cup or container in center of serving platform as indicated.



STEP 4

Open the faucet handle until the desired quantity is dispensed.

DAILY CLEANING



STEP 1

Run a complete brew cycle of *just hot water* into the server and let it set for a minute. Empty the server completely by opening the faucet.



STEP 2

Remove the lid, fill server with cleaning solution and thoroughly clean the inside of server.



STEP 3

Rinse server thoroughly using fresh water rinse.



STEP 4

Fully fill server with sanitizing solution for 5 minutes then drain through fully open faucet.

NOTE: Bunn-O-Matic recommends the 3 step method for cleaning and sanitizing the server. The 3 step method consists of hot soapy water using an approved detergent, a fresh water rinse, and an aqueous sanitizing solution using an approved **non-chlorine** sanitizer. **Do not submerge server.**



USE & CARE INSTRUCTIONS for ThermoFresh® SERVER with DIGITAL SIGHT GAUGE

DAILY CLEANING (Continued)



STEP 5

Remove the faucet handle/stem assembly by unscrewing the faucet nut just behind the faucet handle.



STEP 6

Use cleaning brush supplied with the server to thoroughly clean the fill tube of the lid assembly and the faucet spout.



STEP 7

Wash the entire outside surface of the lid assembly with a mild detergent and water solution and rinse with hot water. **Do not submerge.**



STEP 8

Disassemble the faucet/stem assembly. Thoroughly wash all faucet parts, drip tray and cover in a mild detergent and water solution. Rinse the parts in hot water. Sanitize the parts for five minutes, then air dry completely.



STEP 9

Remove the drip tray and drip tray cover. Thoroughly wash in a mild detergent and water solution. Rinse the parts in hot water.



STEP 10

Reassemble the faucet and attach it to the dispenser. Wash the entire outside surface of the server with a clean damp cloth. Do NOT clean this equipment with a water jet device.