

Libbey 18/o Collection

▸ Stainless Steel

▾ Silverplated



Cresswell
No. 318 ▸

Pieces: 9



Deluxe Windsor
No. 660 ▸

Pieces: 12



Diana
No. 967 ▸

Pieces: 5



Elexa
No. 963 ▸

Pieces: 9



Elexa Satin
No. 663 ▸

Pieces: 9



Fairfield
No. 578 ▸

Cromwell
No. 278 ▾

Pieces: 16

LIBBEY® 18/0 AVAILABILITY GUIDE

Flatware Abbreviation Key: **F.H.** – Flat Handle, **Fl. Bl.** – Fluted Blade, **S.H.** – Solid Handle, **Ser. Bl.** – Serrated Blade, **Pnc.** – Pinched, **Bol.** – Bolster, **Pl. Bl.** – Plain Blade, **H.H.** – Hollow Handle

Refer to page 183
for custom stamping
and made-to-order
silverplating
information.

* Cannot stamp Hollow
Handled knives

+ Square tip handle

✓ Knife has vertical blade

	Silverplated															
		001 American Teaspoon	002 Dinner Spoon	003 Tablespoon	004 Round Bowl Soup Spoon	007 Demitasse Spoon	016 Bouillon Spoon	021 Ice/Tea Spoon	027 Dinner Fork	029 Cocktail Fork	030 Utility/Dessert Fork	038 Salad Fork	039 European Dinner Fork	053 Butter Spreader, F.H.	*254 Bread & Butter Knife, H.H.	*2691 Dessert Knife, Ser. Bl. H.H.
																
		6¾	7			4½	6¾		8	5½		7½		6½		
	039	6	7¼				5½		7½		7¼	6½				
	813	6¼	7¼	8¾	7¼	4¾	6½	7½	8½	4¾	7¼	6½	8½	6½	6¾	
		6	6¾				6				7¾	7				
	305 ^A	6	7½	8½		4¼	5¾	7¾	7¾	5½	7¼	6½	8	6½		
	056	6	7½	8½			5½	7½		5½	7	6	8	5½		
		6	7½			4¾	5½		8½	6		7¼		6½		
		5½	7¾	8½		4½	5½	7½			7	6½				
		6¼					6½				7¼	6½				
		6½	8½			5½	7		8½	5¼	7			5¼		
		6½	8½			5½	7		8½	5¼	7			5¼		
	278 ^B	6	7¼	8¼		4¼	5¾	7½	7½	6	7	6½	8¼	5½		
		6¼	7¾		7¼						7¼		8½			
		6½	7½				6¼	7¾	8	5½		7				
	911 ^C	6½	7				6		7½		7½	6½	8¼			
	844	6	7¼	8¾		4¼	5¾			6	7¼	7	8¼			
		5½	6½				5¾				7¼	6¼				
		5½	7½	8½		4½	5½	7½			7½	6½	8¼			
		6¼	7½			4¾	6½	7¾	7½	5½	7½	6½	8¼			

^AClassic Rim 918 is Priscilla 305 when silverplated ^BFairfield 578 is Cromwell 278 when silverplated ^CHigh Society 511 is Silhouette 911 when silverplated

LIBBEY 18/0 COLLECTION 173