

OWNER'S MANUAL

PROSERVE MEAL DELIVERY CARTS

This manual applies to the following Cambro products:

Low Profile Meal Delivery Carts:

MDS1520S20

MDS1520S2R

MDS1418S20

MDS1418S2R

Tall Profile Meal Delivery Carts:

MDS1520T6

MDS1520T6R

MDS1520T8

MDS1520T8R

This Owner's Manual provides you with a step-by-step guide to cleaning and maintaining your Meal Delivery Cart. If you have further questions, please contact your Cambro Sales Representative, visit our website www.cambro.com, or call our Customer Service Department at USA 800 833 3003, 714 848 1555, N. Ireland & UK 0800 587 0057, Ireland 1800 509 046.



MDS1520T6



MDS1520T8



MDS1418S20

CAMBRO
Healthcare

www.cambro.com

I. Cleaning and Maintenance

A. Cleaning Instructions

1. Clean with mild soap (dish detergent). Power washing is permitted.
2. Hand wash using soft nylon scrub to clean all interior and exterior surfaces.
3. Rinse with hot water.
4. For tougher stains, mild abrasives such as baking powder and white vinegar may be used.

WARNING: Do not use detergents or cleaners containing ammonia, bleach or harsh chemicals.

WARNING: Do not use steel wool or abrasive scrub pads or brushes.

WARNING: Do not tip cart forward and lean on its open doors to drain or air dry.

1. Effective solutions for removing scents and stains:

- Use a standard destainer or
- An odor removing soap or
- Sanitizer or
- A diluted solution of 2-3 tablespoons of baking soda per 4 liters of hot water or
- 1 part lemon juice to 4 parts hot water or
- 1 part white vinegar to 4 parts hot water.

2. After cleaning rinse thoroughly with hot water and dry thoroughly.

B. Caster Maintenance

Caster maintenance should be performed after every cleaning.

1. Grease swivel raceway of caster using a lubricant such as Lubriplate #930-AA, Keystone #84EPXLT multi-purpose grease or equivalent. Apply grease using a grease gun with a needle nose adapter or a tube-type applicator such as Sta-lube Moly-graph Assembly Lube (Fig.1). These can be obtained at most auto parts stores.
2. Use a light oil such as WD-40 on the hub (Fig.2).
3. Check caster for damage and test caster spin and swivel rotation before returning to service.



Fig. 1



Fig. 2

II. Cambro Warranty

Cambro warrants to the original buyer that if a product proves defective:

1. Within 1 year from the date of manufacture, Cambro will replace the product free of charge; or,
2. After 1 year and up to 2 years from the date of manufacture, Cambro will grant a credit of $\frac{2}{3}$ off replacement product; or,
3. After 2 years and up to 3 years from the date of manufacture, Cambro will grant a credit of $\frac{1}{3}$ of the original price towards a replacement product.

ABUSE OR MISUSE WILL VOID THIS WARRANTY

In the event of a defective product, your Cambro Sales Representative will collect appropriate information, such as date of manufacture and invoice information for warranty process. With proof of purchase to the original owner, Cambro Manufacturing will replace the product to the original owner.

NOTE: Your Cambro Sales Representative will determine if the product should be returned for inspection before issuing credit.

III. Replacement Parts

Please visit www.cambro.com for a complete list of replacement parts. The model number of the Cambro cart is required to determine the correct replacement part. The cart model number can be found on the end of the cart above the bumper for all carts.

TO ORDER REPLACEMENT PARTS:

- Call Cambro Customer Service at 800.854.7631 or
- Call your local Cambro Representative or Distributor