




Medina Series™
96" Conference Table
Model No. MNC8



ASSEMBLY INSTRUCTIONS

CALL 1-800-822-8037 FOR ASSISTANCE

PARTS LIST

Name	Part	Qty.	Spare Qty
A	 REALS001 Cam Lock	14	1
B	 REALS102SLV Cam Sticker/Silver	14	1



Name	Part	Qty.	Spare Qty
C	 REALS003 Cam Post	14	1


NOTE:

- ①. 1 Top and 2 Modesty Panels with Hardware packed in one carton - MNCT96
- ②. 2 Legs with Hardware packed in one carton - MNCB

Items with HB are in hardware box.

PARTS LIST

Name	Part	Qty.
H	 MNCT96** Top	1
J	 MNCB** Leg	2

Name	Part	Qty.
K	 MNCT96K** Modesty Panel	2


**Denotes Color Code

2

IMPORTANT!

Review ALL instructions before beginning assembly. These instructions are provided to avoid problems that may occur from improper assembly or installation. Mayline and/or its distributor are not responsible for failure resulting from improper assembly or installation of this product. Moreover, all warranties are void for failure to follow these assembly instructions.


- 1 Insert Cams (A) into the Modesty Panel (K) and MNCB Legs (J). Install Cam Posts (C) into threaded inserts in MNCB Legs (J). Attach Modesty Panel (K) to MNCB Legs (J) by turning Cams (A).



NOTE: The arrow on the face of the Cam (A) should point towards the Cam Post (C) for proper alignment.



3

- ② Install Cam Posts (C) into threaded inserts in underside of Top (H).



4

- ③ Place Top (H) onto Leg (J) and Modesty Panel (K) and lock in place by turning Cams (A). Apply MNCB Cam Sticker onto Cams (A) of Legs (J). Apply Cam Stickers/Silver (B) onto Cams (A) of Modesty Panel (K). Insert Grommets into Top holes.



NOTE: The arrow on the face of the Cam (A) should point towards the Cam Post (C) for proper alignment.

5