

Silva Soak

Powder formula for presoaking and
detarnishing sterling silver and silver plate.



CONCENTRATED

Manual Warewashing Presoak & Tarnish Remover

Removedor de deslustre y pre-remojo concentrado para lavada manual de platos

Manufactured for:
Clark Core Services, LLC
2205 Old Philadelphia Pike
Lancaster, PA 17602
1-888-256-6400



GENERAL DESCRIPTION

SILVA SOAK is an alkaline powder designed for use as a presoak for silverware and silver table service. It also removes tarnish and stains from silver plate and sterling silver utensils. When used as directed, SILVA SOAK will not harm fine and precious silver. It quickly penetrates and saturates soils for their more efficient removal in the dishwashing machine. SILVA SOAK readily dissolves and produces excellent cleaning results in both hard and soft water. SILVA SOAK's tarnish eliminating procedure removes sulphur type tarnish and stains with an easy application in a soak solution utilizing aluminum foil. SILVA SOAK is highly concentrated and can be significantly diluted for economical use.

PHYSICAL PROPERTIES

Chemical Composition: Synthetic soil penetrating and soil suspending agent; oxide removal agents; water conditioning agents.

Appearance..... Yellow Powder
Stability..... 1 Year@Ambient Temperature
Wetting Ability..... Excellent
Foaming..... Moderate
Solubility..... Complete and Fast

PACKAGING

147SILVASOAK8: (4) 8 lb. Plastic Jars - 32 lb. net / 35 lb. gross

999SILVASOAK: (1) 8 lb. Plastic Jar - 8 lb. net / 8.75 lb. gross

DIRECTIONS

Place silverware in solution of 2 oz. SILVA SOAK per gallon of water at a temperature of 140°F to 150°F with the ware in contact with aluminum foil or an aluminum container. Electrolytic action takes place, which provides lift and scrubbing action. Leave silverware in the solution for 10 to 15 minutes. (Do not leave silverware in the solution, in contact with aluminum, for longer periods as the aluminates formed may deposit on the ware.) When presoaking knives, place them in the solution in such a way that the blades (all those made of stainless steel) do not contact the aluminum directly. As a presoak for film removal on stainless steel tableware, use same concentrations and temperatures.

NOTE: Do not use aluminum containers or aluminum foil with stainless steel tableware. Contact with aluminum and stainless steel soaking in detergent solution can cause attack on both metals and damage to the surface of the stainless steel tableware. Also, chlorine type tarnish (caused by bleach or chlorine dishmachine compounds, and grey or black in color) is not removed by SILVA SOAK. Hand polishing with silver creams is appropriate for this job.

HANDLING PRECAUTIONS

CAUTION

**MAY BE HARMFUL IF SWALLOWED.
KEEP OUT OF REACH OF CHILDREN.**

FIRST AID

EYES: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician. **SKIN:** IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. **INHALATION:** IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. **INGESTION:** IF SWALLOWED: Rinse mouth. DO NOT induce vomiting.

Seller makes no warranty, expressed or implied, concerning the use of this product other than indicated on the label. Buyer assumes all risk of use and/or handling of this material when such use and/or handling is contrary to label instructions.

See the product label and SDS for a complete list of precautionary statements.