

# **GARDE**

## **USER MANUAL**



# **Cheese Blocker**

Item #181CHEESBLKW

# **GARDE**

## **USER MANUAL**

Please read and comply with the instructions listed on this document. To get the best service life and performance from your machine, clean it thoroughly before and after each use by following the instructions listed below. Minimize the use of alkaline cleaners as they may dull the finish and cause pitting.

### **Operation**

- 1) Place the unit on a sturdy work surface.
- 2) Using the handle, lift and hold the cutting wire in the upright position.
- 3) Place cheese block on the cutting surface. Make sure the part of the cheese that is to be cut is on top of the groove.
- 4) Gently pull handle so that tension is added to the cutting wire.
- 5) While maintaining tension on the cutting wire, slowly but firmly lower the handle and press the cutting wire through the cheese block.

### **Cleaning and Maintenance**

- 1) Remove the cutting wire.
- 2) Thoroughly clean the main frame and the cutting wire.
- 3) Dry all components and re-assemble the unit.

### **Replace Cutting Wire**

- 1) Firmly grasp the handle with both hands and twist both sides in opposite directions to separate the two halves. Unhook the cutting wire.
- 2) On the bottom of the unit, unhook the opposite end of the cutting wire. Remove the old cutting wire from the unit.
- 3) Hook one end of the new cutting wire on the bottom of the unit.
- 4) Wrap the opposite end of the cutting wire around the pulley system. Make sure the wire is placed within the groove of the pulley wheel.
- 5) Feed the end of the wire through the gap in the cutting surface and hook the other end of the cutting wire to the screw located inside the handle.
- 6) Reconnect both halves of the handle by twisting in the opposite direction that you twisted in step 1.

# **GARDE**

## **USER MANUAL**

### **Replacement Parts**



**Cutting Wires 12pk  
#181CHSWIRE12**



**Cheese Blocker Feet 4pk  
#181CHSBLKFT**



**Cheese Blocker Handle  
#181CHSBLKHDL**



**Cheese Blocker Springs  
#181CHSSPRING**



# EQUIPMENT LIMITED WARRANTY

Garde warrants its equipment to be free from defects in material and workmanship for a period of 1 year. This is the sole and exclusive warranty made by Garde covering your Garde brand equipment. A claim under this warranty must be made within **1 year** from the **date of purchase** of the equipment. Only the equipment's original purchaser may make a claim under this warranty. Garde reserves the right to approve or deny the repair or replacement of any part or repair request. The warranty is not transferable. Garde Equipment installed in/on a food truck or trailer will be limited to a period of **30 days** from the original date of purchase.

## To Make a Warranty Claim:

For Warranty Inquiries contact the location where you purchased the product:

- **WebstaurantStore.com:** Contact [help@webstaurantstore.com](mailto:help@webstaurantstore.com). Please have your order number ready.
- **The Restaurant Store:** If you purchased this unit from your local store, please contact your store directly.
- **TheRestaurantStore.com:** Online purchases, call 717-392-7261. Please have your order number ready.

Failure to contact the designated location prior to obtaining equipment service may void your warranty.

Garde makes no other warranties, express or implied, statutory or otherwise, and **HEREBY DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE.**

## This Limited Warranty does not cover:

- Equipment sold or used outside the Continental United States
- Use of unfiltered water (if applicable)
- Blades. They are expected to wear down and be replaced by user on a consistent basis dependent upon frequency of usage.
- Garde has the sole discretion on wearable parts not covered under warranty
- Equipment used for residential or other non-commercial purposes
- Equipment not purchased directly from an authorized dealer
- Equipment that has been altered, modified, or repaired by anyone other than an authorized service agency
- Equipment where the serial number plate has been removed or altered.
- Damage or failure due to improper installation, improper utility connection or supply, and issues resulting from improper ventilation or airflow.
- Defects and damage due to improper maintenance, wear and tear, misuse, abuse, vandalism, or Act of God.

Any action for breach of this warranty must be commenced within 1 year of the date on which the breach occurred. No modification of this warranty, or waiver of its terms, shall be effective unless approved in a writing signed by the parties. The laws of the Commonwealth of Pennsylvania shall govern this warranty and the parties' rights and duties under it. Garde shall not under any circumstances be liable for incidental or consequential damages of any kind, including but not limited to loss of profits.